# Motherboard Z3735F BIOS update steps

1．Format a USB flash disk to FAT32 and extract the BIOS file into the U disk root directory.

2．Connect the U disk to motherboard Z3735F

3．Turn it on, press **Delete** into BIOS

4．Choose **SAVE & EXIT**

5 . Choose *Launch EFI Shell from filesystem device* and press Enter

6 . Input **fs1** and press Enter

7 . Input *f* to begin to update the BIOS. Please DO NOT cut off power supply before the end, or

else the motherboard has to be returned to repair.

8 . Please reboot it after the end of update.